



TEL:01594 841014

SHREDDER TIP SHEET

Always read manufacturer's instruction manual in full.

If required use an extension cable suitable for heavy use, capable of carrying a full 13Amp load over the full distance of the cable run. **MINCOST Recommends the use of blue-sheathed 13Amp cable for running powerful shredders.**

Wherever possible always try to plug your shredder directly into the household ring main circuit. Avoid outhouse and extensions to buildings, as the electrical supply may only be suitable for light load appliances.

In the interest of safety try to ensure that your household socket has protection against earth faults, so that in the rare event you're outside appliance or cable may develop a fault or be damaged, that the circuit is automatically switched off. If in doubt seek advice from your local electrician.

Always switch off at the mains and disconnect before removing any covers to work on your shredder to prevent accidental operation. All of our shredders are fitted with a safety switch so as if the shredder hopper/ cover is not fitted correctly the machine cannot start.

All **VIKING shredders are fitted with an electro-magnetic operation switch so as if mains power is disconnected then re connected at any point the shredder must be manually switched on to continue operation this feature is to prevent operator injury.**

All **VIKING shredders are fitted with motor thermal overload protection so if an operator overloads and stalls the shredder in use the machine will automatically shut down, this feature is designed to prevent damage to your shredder, it maybe several minutes before the motor cools enough to allow continued operation. *This feature will also be triggered if the electrical supply is insufficient!***

If after you have read the manufacturers instructions in full and have any questions or experience problems with you machine please don't hesitate in contacting us on the above number or call in to see us. We are here to help.